Dongle installation for Windows 7, 8.1, 10

For Windows 8.1, 10 64bit the dongle driver do need a signature. Therefore the ATB dongle driver do not have it the process "Disable Driver Signature Enforcement" is required.

1. Start the operating system.
2. Windows 8.1: move the mouse in the upper right corner and click on Settings.
   Windows 10: Click on the Windows icon (start) at the bottom left
3. On the symbol "ON / OFF" button.
4. Shift Capitalize, click "Restart".
5. Only Windows 8.1: In the "Options" menu → "reboot"
6. In "Select Options"   →"Troubleshooting"
7. In "Troubleshooting"   → "Advanced Options"
8. In "Advanced Options"   → "Start settings"
9. In "Start settings"   → "Restart"
10. After the restart with the number "7" key "7 Driver Signature Enforcement
                                                              disable "call.

In the following time the operating system no signature is required when installing the dongle driver.

Installing the dongle driver

Connect the dongle to the USB connector, place the installation CD-ROM into the DVD drive
1. Windows 7:   Start menu   → "Control Panel"
1. Windows 8.1:   Calling up menu "This PC" with Windows key + 1
                     In "This PC"   → "Control Panel"
1. Windows 10:   Click on the Windows icon (start) at the bottom left
                     In the menu   → "Settings"
2. Windows 7, 8.1: In the "Control Panel"   →"Hardware and Sound"
                     In "Hardware and Sound" → "Devices and Printers" →"Device Manager"
2. Windows 10:   In the "Settings"   → "Device"
                     In "equipment"   → "Connected bone"
                     In "Connected devices"   → "Device Manager"
3. Windows 7, 8.1: In "Device Manager"   → Other devices "ATB-LOCK USB" on
                                                     yellow triangle attention.
3. Windows 10:   In "Device Manager"   → "USB", "ATB-LOCK USB" on yellow
                                                     Triangle eighth.
4. Windows 7, 8.1, 10: Click "ATB-LOCK USB" → "Properties ATB-LOCK USB"
5. Windows 7, 8.1, 10: In "Properties ATB-LOCK USB" → "Drivers"
6. Windows 7, 8.1, 10: In "Drivers" → "Update Driver"
7. Windows 7, 8.1, 10: In "Update Driver Software - ATB-LOCK USB" → "The computer
                                                     Search for driver software "
8. Windows 7, 8.1, 10: In the following menu → "Search" and the DVD
                                                     Select drive: "Next"
9. Windows 7, 8.1, 10: With "Browse" select the DVD drive → "OK" to complete
9. Windows 7, 8.1, 10:   In "Windows Security" → "install driver software anyway"
10. Windows 7, 8.1, 10: The driver has been installed → "Close"